

HVO Summit



Name: 41 plies **es42**

BUFFER Mode :
Distance - Ft

OIL Mode :
Distances - Ft
leftoutside :
lefttrack :
leftinside :
rightinside :
righttrack :
rightoutside :

Transfer Rate %

SPEED SETTINGS:

Travel
Condition
Strip

<p>Pass 1</p> <p>Forward: 42 Reverse: 33.0 Double</p>		<p>Pass 2</p> <p>Forward: 28.0 Reverse: 23.0 Double</p>	
<p>Forward: 17.0 Reverse: 14.0 Double</p>		<p>Forward: 11.0 Reverse: 11.0 Double</p>	
<p>Forward: 30.0 Reverse: 25.0 Double</p>		<p>Forward: 19.0 Reverse: 14.0 Double</p>	
<p>Forward: 38.0 Reverse: 33.0 Double</p>		<p>Forward: 28.0 Reverse: 23.0 Double</p>	
<p>Forward: 38.0 Reverse: 33.0 Double</p>		<p>Forward: 28.0 Reverse: 23.0 Double</p>	
<p>Forward: 30.0 Reverse: 25.0 Double</p>		<p>Forward: 19.0 Reverse: 14.0 Double</p>	
<p>Forward: 17.0 Reverse: 14.0 Double</p>		<p>Forward: 11.0 Reverse: 11.0 Double</p>	
<p>Forward: High Reverse: High Medium Medium</p>		<p>Forward: High Reverse: High Medium Medium</p>	
<p>Forward: 100 Reverse: 100 Double</p>		<p>Forward: 80 Reverse: 80 Double</p>	

Short Run Mode: Off
Turn-around Distance: 0.0 Ft

Shipping Mode: Full
Start: 0.0 Ft
Cleaner Pad Distance: 61.5 Ft
Vacuum: On Start

Cleaner Flow
In oil: 100 %
Back lane: 85 %

